




Disinfectants & Sanitizers

Chemical Compatibility

- Most disinfectants with Quaternary Ammonium, Hydrogen Peroxide, and Bleach based sanitizers can be used with can be used with all models with brown Viton® seals. 
- Alcohol or Ammonia based disinfectants & sanitizers are best used with the *Smith Performance Acetone Sprayer* or *Acetone Mister* shown below.

Application

- If fine misting is required, use our misting nozzles part # 182937 & 182938.
- Our brass adjustable cone nozzle can be adjusted to a fine spray for wetting applications.
- When using *bleach based chemicals*, use the poly adjustable tip or one of the misting nozzles, brass nozzles should not be used.



190571



190515



190462



190348



190450



190398

High Atomization Misting Nozzles



Part# 182937
0.058 GPM @ 30PSI
0.067 GPM @ 40PSI



Part# 182938
0.088 GPM @ 30PSI
0.100 GPM @ 40PSI

